





MODEL 146 DP INDICATOR



MODEL 146 DP SWITCH  
WITH HIRSCHMANN CONNECTOR

